

Soldering Type N Male, two piece, water proof connector



1.Strip center conductor 13mm



2.Strip shield 10mm



3.Cut braid shield 1.5mm



4. Screw connector onto the cable.
Make sure you can see the center conductor through the tiny hole in the center pin.



5. Solder center conductor



6. Solder shield



7.Screw on the outer sleeve to the inner body.

Check with an ohm meter that there is no connection between center and shield.